

**Information Brochure for Beekeeper Garment
According to PSA-Regulation (EU)2016/425 (Personal Protective Equipment)**

here: art.-no. 78JR3D beekeeper jacket "3D", only usable in combination with hood round art.-no. 78HSR (-> 78JHR3D) or hood english art.-no. 78HA (-> 78JHRA3D)
art.-no. 78O3D beekeeper overall "3D", only usable in combination with hood round art.-no. 78HSR (-> 78OH3D) or hood english art.-no. 78HA (-> 78OHA3D)

Representative: see invoice

The PPE protects against bee stings by preventing bees from entering. Since the bee sting is shorter than the holes in the 3D Material, the product offers additional sting protection.

The garment fulfills the basic requirements of PSA-Regulation (EU)2016/425. Prototype testing was done by TÜV Rheinland LGA Products GmbH, Tillystraße 2, D-90431 Nürnberg, identification no. 0197.

Selection of the most appropriate garment must be based on a risk analysis. The garment has to be tried on to determine the required size and to ensure a proper fit. To ensure safety, please make sure that the garment is worn always with the associated hood round or english, well and completely closed. Both hoods are usable and changeable from Size S – XXL. Knitted cuffs and elastic bands have to be closed and fitted, in order to avoid the invasion of bees. To ensure full body protection the jacket can be combined with trousers art.-no. 78HO, for example. In this case it should be noted, that the two parts match in size. The parts should be always be well and seamlessly connected by the elastic band of jacket. The correct fit must always be checked so that there is no gap when you raise your arms, for example.

Before put on, the garment has to be checked for damages. We recommend that any necessary repairs be carried out by suitable and competent companies. In order not to affect the performance of the garment, we advise against carrying out the repair yourself.

When not in use, the garment has to be stored properly, i.e. in a dry, vermin free room. Incorrect storage can cause damage to the product, which can compromise protection. Since this is a natural product, it may suffer from humidity and temperature fluctuations during storage and natural material changes may be observed over time. For these reasons, it is not possible to specify a date of expiry. Furthermore, the expiry time varies depending upon the degree of wear and tear and the field of application. Disposal can be carried out with household waste or old clothes collection containers.

If the garment is combined with a headgear with zipper, the headgear must be removed before washing and is only washable by hand.



5 X



do not bleach



not suitable for the dryer



do not iron



do not dry clean

The garment (without headgear) is washable up to 30 ° C.



5 X



do not bleach



not suitable for the dryer



do not iron



do not dry clean

After washing both parts has to be fitted together again and prior to re-use, the garment has to be checked for damages and replaced, if necessary.

The following sizes are available:

Size		(A) Chest	(B) Height	
XS	(42/44)	86 – 91 cm	172 – 178 cm	
S	(46/48)	90 - 97 cm	168 - 176 cm	
M	(50/52)	98 - 105 cm	174 - 182 cm	
L	(54/56)	106 - 113 cm	180 - 186 cm	
XL	(58/60)	114 - 121 cm	184 - 188 cm	
XXL	(62/64)	122 - 128 cm	187 - 192 cm	

This measurement information is only a general recommendation. Deviations could be possible.

At present we are not aware of any product-related substances that might adversely affect the health of the user.

However, it should be noted that wearing the hood can impair the field of vision and possibly also the hearing range. Improper use of the garment can also lead to impairments. The article is to be used exclusively for beekeeping work on the bees.

Material specification 3D fabric: 100 % polyester, pockets, fabric attachments and knitted cuffs: 100 % polycotton
inner part knee: 100 % PE foam

The marking affixed to the garment or the smallest packing unit contains relevant information on:

-Manufacturer	Bovie GmbH & Co. KG, Industriering 46, 41751 Viersen, Germany
-Type designation	78JR3D, 78O3D
- Specified requirements	PSA-Regulation (EU)2016/425 2PFG 2599:2019

You can view the declaration of conformity for the product here: www.bovie-imkerschutz.de state: 12/2020